

GLOSSY ON GOOSE NECK




Wall light with reflector on gooseneck. The toggle switch is located on the bottom of the base.

RP EUR incl. VAT

R10543

GLOSSY on a goose neck chrome 230V LED
GU10 8W

58,00



3D model



PDF manual

G11841

