

# WOODY FLOOR BASE


Wooden floor stand with E27 socket. The power switch is located on the E27 socket for easy access. Suitable shades: DELISA 35/30, CONNY 25/30, CONNY 35/30, RON 40/25, TEMPO 30/19.

RP EUR incl. VAT

R11790

WOODY floor lamp base oak 230V E27 25W

138,00



 3D model

 manual

G13026

